

## Appendix - Aurora DMX Control Specification - Software V1.6.1

**Note:** Both Channels 0 and 1 set the DMX base address of Aurora to 1.

DMX Channel	Value	Function
1	0-255	<b>Brightness</b>
2	0-8 9-16 17-24 25-32 33-41 42-49 50-57 58-65 66-74 75-82 83-90 91-98 99-106 107-115 116-123 124-131 132-139 140-148 149-156 157-164 165-172 173-180 181-189 190-197 198-205 206-213 214-222 223-230 231-238 239-246 247-255	<b>Palette Select</b> Royal Sunrise Stained Glass Crest Galaxy Blue and Orange Northern Lights Pink Blue Cyan Pink Cyan Candy Red + Green = Yellow Purple Thermometer Hot Coals Hot Pink Coastal Water Leafy Green Halloween Valentine Christmas St Patrick's Day Winter All White Cool White Off White Warm Yellow Yellow and White Rainbow 1 Rainbow 2 Rainbow 3 Spun Sugar Sweet Treats
3	0-14 15-29 30-44 45-59	<b>Pattern Select</b> Plasma Spectrum Waves Waterfall

	60-74 75-89 90-104 105-119 120-134 135-255	Sweep Twinkle Starry Sky Expander Solid Color Flash-Bang
4	0-255	<b>Transition Duration</b>
5	0-255	<b>Speed</b>
6	0-255	<b>Energy</b>
7	0-255	<b>Variance</b>
8	0-255	<b>Decay</b>
9	1-127 128-255	<b>Audio Reactive Toggle</b> Audio Reactive Mode Non-Audio Reactive Mode