

## Appendix - Aurora DMX Control Specification - Software V1.9.1

**Note:** Both Channels 0 and 1 set the DMX base address of Aurora to 1.

DMX Channel	Value	Function
1	0-255	<b>Brightness</b>
2	0-7 8-15 16-23 24-31 32-39 40-47 48-55 56-63 64-71 72-79 80-87 88-95 96-103 104-111 112-119 120-127 128-135 136-143 144-151 152-159 160-167 168-175 176-183 184-191 192-199 200-207 208-215 216-223 224-231 232-239 240-247 248-255	<b>Palette Select</b> Royal Sunrise Stained Glass Crest Galaxy Blue and Orange Northern Lights Pink Blue Cyan Pink Cyan Candy Red + Green = Yellow Purple Thermometer Hot Coals Hot Pink Coastal Water Leafy Green Halloween Valentine Christmas St Patrick's Day Winter Red and White All White Cool White Off White Warm Yellow Yellow and White Rainbow 1 Rainbow 2 Rainbow 3 Spun Sugar Sweet Treats
3	0-14 15-29 30-44	<b>Pattern Select</b> Plasma Spectrum Waves

	45-59 60-74 75-89 90-104 105-119 120-134 135-255	Waterfall Sweep Twinkle Starry Sky Expander Solid Color Flash-Bang
4	0-255	<b>Transition Duration</b>
5	0-255	<b>Speed</b>
6	0-255	<b>Energy</b>
7	0-255	<b>Variance</b>
8	0-255	<b>Decay</b>
9	1-127 128-255	<b>Audio Reactive Toggle</b> Audio Reactive Mode Non-Audio Reactive Mode